



Roku 2 Remote Control Buttons Replacement

Replacing old or worn-out buttons on your Roku 2 remote.

Written By: Alex Saltos





TOOLS:

- [Phillips #000 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Remote Battery



- Turn over remote and press down on tab to remove.

Step 2



- Remove batteries

Step 3 — Remote Control Buttons



- After removing the batteries use the 000 phillips to remove the screw

Step 4



- Use the plastic opening tools to pry open the remote.

Step 5



- Lift the top of the remote off very carefully so that board does not fall

Step 6



- Remove and replace buttons

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-25 05:37:27 AM.